

## **LOADING OF (ISO) PENTANES**

Pentane loadings are defined as pure (iso) pentanes and all different blends in which one of the components is an (iso) Pentane. For a list of (iso) pentanes and (iso) pentane blends please revert to the table below.

### **Loading of pentane or pentane bends**

Vopak OSV will not load (iso) pentane or (iso) pentane blends in more than one compartment per truck. If the quantity of the order requires loading in more than one compartment, the truck will be refused by Vopak OSV and Shell will be notified.

Loading of only one (iso) pentane order or (iso) pentane blend order per truck is allowed. The truck tank temperature must be below 35 degrees Celsius before loading will begin.

### **Loading of pentane or pentane blends during summer**

When temperatures of 20 degrees Celsius and over are expected, loading of (iso) pentane or (iso) pentane blends is only possible within limited hours. Available loading times will be from 07:00 hours until 11:00 hours and from 19:00 hours until 23:00 hours.

The time in between is not available for loading of (iso) pentane or (iso) pentane blends and slots will be blocked by the Driver Desk Representative of Vopak OSV.

### **Combined loading**

Loading of only one (iso) pentane order or (iso) pentane blend order is allowed. This order may however be combined with other orders if these orders are not (iso) pentane orders or (iso) pentane blend orders.

Note that Vopak and Shell strive for a maximum of in total two orders per truck and a maximum of three compartments per truck.

<b>Q-nummer</b>	<b>Product</b>
Q1111	Iso Pentaan-P
Q1113	Pentaan 75/25 mix-B
Q1114	Pentaan 78/22 mix-B
Q1116	Pentaan-P
Q1117	Pentaan mix UK-B
Q1123	Pentaan blend B70/30
Q1124	Pentaan blend 25/75
Q1127	Pentaan 73/27 mix-B
Q5113	SBP 40/65-B